

SERVICE BULLETIN – 01/ JANUARY 2007

SV SERIES THERMOSTATIC EXPANSION VALVE

Here below the chart showing the setting of the Thermostatic Expansion Valve (TXV) used on SV Series.

Model	TXV Part Nbr	Danfoss Part Nbr	Nozzle size	Setting
SV 135	CM 81453621	68Z3520	No. 2	Open 1/2 turn (ccw) from Danfoss standard setting
SV 215	CM 81453620	68Z3520	No. 3	Open 1/2 turn (ccw) from Danfoss standard setting
SV 315	CM 81453620	68Z3520	No. 3	Open 1 turn (ccw) from Danfoss standard setting
SV 385	CM 81453986	68Z3520	No. 4	Open 1 turn (ccw) from Danfoss standard setting
SV 535	CM 81453840	68Z3520	No. 5	Open 1 turn (ccw) from Danfoss standard setting